

GloWire Installation Instructions

1. Measure out the path of the GloWire, and trim it to your specifications. At the point you cut the wire, remember to put the black end-cap back on.
2. Decide where you are going to mount the inverter, and do so. Connect the cigarette adapter to any 12V source or switch. **DO NOT CUT OFF THE INVERTER!**
3. Create a bead of the included GloWire adhesive, tracing out the path that you want your GloWire to take. Remember that this installation will be permanent!
4. Carefully lay down the GloWire over the bead you have made and push firmly into place. Allow to dry and your installation is complete.
5. **Remember to turn on the GloWire using the on/off switch located on the end of the cigarette adapter.**