




**B R E A T H E  
C O N T R O L L E R**

**FOR USE WITH PLASMAGLOW LIGHTING EYES ONLY**  
**Using with any other product may overload**  
**the controller and void your warranty.**

INPUT SIDE

OUTPUT SIDE



### **Installation Instructions:**

1. Install your PlasmaGlow Lightning Eyes but do not perform wiring portion of installation.
2. Mount the PlasmaGlow Breathe Controller in an area to which you can wire each of the 2 Lightning Eyes strips. Keep the controller and wiring clear of moving parts, water and excessive heat.
3. Connect the 2 wires on the input side of the controller to a power source. You can use the running lights, headlights or a switch. Connect the red wire to a 12V(+) Positive source and connect the black wire to Ground 12V(-).
4. Connect the red and black wire for one output to the positive and negative wires (respectively) for one of the Lightning Eyes strips. Repeat for the other strip using output 2. The order does not matter, as long as **ONLY ONE STRIP** is connected to each output.
5. Take care that all of your wire connections are secured and insulated.

### **DON'T FORGET TO REGISTER YOUR WARRANTY**

To ensure a trouble free experience if you ever experience a defect in manufacturing or workmanship, be sure to register your warranty on our website at [www.plasmaglow.com](http://www.plasmaglow.com). If you do not register your warranty we may not be able to help you if your product fails unexpectedly.

**ONLINE AT [www.plasmaglow.com](http://www.plasmaglow.com)**